

DATA COMMUNICATION

INTRODUCTION


- ▶ Data Concept
- ▶ Analog and Digital Signal
- ▶ Periodic and Non-Periodic Signal
- ▶ Sine Wave
- ▶ Wave length
- ▶ Time and Frequency Domain
- ▶ Composite Signal
- ▶ Bandwidth
- ▶ BPS and Bit Length

DATA.....

- Data is a usable to a person or application .
- Data should be transmitted from one place to another in the form of electromagnetic signals across a transmission medium.
 - *TO BE TRANSMITTED, DATA MUST BE TRANSFORMED TO ELECTROMAGNETIC SIGNAL*
- Signals are divided into two categories
 - ANALOG SIGNAL
 - DIGITAL SIGNAL


COMPARISON OF ANALOG AND DIGITAL SIGNALS

Value



Analog Signal

Value



Digital Signal

ANALOG SIGNAL & DIGITAL SIGNAL

- ▶ Analog data refers to information that is continuous with respect to time and frequency.
- ▶ Signal has infinitely many levels of intensity over a period of time
- ▶ As the wave moves from place A to place B, it passes through and includes number of values along its path
 - Examples:
 - An analog clock(hours, minutes and sec.)
 - Human Voice
- ▶ Digital signal refers to a information that has discrete states.
- ▶ Signal has limited number of defined values
- ▶ Each value can be either 1 or 0
 - Examples:
 - A Digital clock(Suddenly change from 10:02 to 10:03)
 - Computer Memory(Data stored in form of 0s and 1s)


Periodic and Non-Periodic Signals

- ▶ Both analog and digital signals can take one of two forms : periodic or non-periodic
- ▶ A Periodic signal complete a pattern within a measurable time span or time frame, and repeats that pattern over subsequent identical periods.
 - Commonly used in analog signals, because they need less bandwidth.
- ▶ A non-periodic signal changes without exhibiting a pattern or cycle that repeats over a time.
 - Commonly used in digital signals, because they can represent variation in data.



Sine Wave

- ▶ A sine wave is the most fundamental form of a periodic analog signal




A Sine wave can be represented by three parameters:

- Peak Amplitude
- Frequency
- Phase

Sine Wave

▶ Peak Amplitude



- The peak amplitude of a signal is the absolute value of its highest intensity, proportional to the energy it carries.
- Normally measured in VOLTS.



Sine Wave

► Frequency


- Frequency refers to the number of period in 1 sec.
- Formally expressed in Hertz(Hz), which is cycle per sec.
- Period refers to the amount of time , in seconds , a signal needs to complete 1 cycle.
- Period is the inverse of frequency and vice-versa.
 - $F=1 / T$



Sine Wave


▶ Phase

- Phase describe the position of the waveform relative to time 0.
- Wave as something that can be shifted backward or forward along with time axis, phase describe the amount of that shift.
- Measured in degrees or radian
 - A phase shift of 360 degree correspondence to a shift of a complete period.



Wave Length


- ▶ Wavelength binds the period or the frequency of a simple sine wave to the propagation speed of the medium
- ▶ It is the distance a simple signal can travel in one period



$$\text{Wavelength} = \text{propagation speed} * \text{Period}$$


Time & Frequency Domain

▶ Sine wave by using Time-Domain Plot



A sine wave in the time domain with peak value 5V and frequency 5Hz


▶ Sine wave by using Frequency-Domain Plot



A sine wave in the frequency domain with peak value 5V and frequency 5Hz

Composite Signal



- ▶ Composite signal is a combination of simple sine waves with different frequencies, amplitudes and phases.
- ▶ It can be periodic or non-periodic.
 - A periodic composite signal can be decomposed into a series of simple sine waves with discrete frequencies, that have integer values(1,2,3, and so on)
 - A non-periodic composite signal can be decomposed into a combination of an infinite number of simple sine waves with continuous frequencies, that have real values



A composite periodic signal

Bandwidth

- ▶ The range of frequencies contained in a composite signal is its bandwidth.
- ▶ It is normally a difference between two numbers.
 - Example:
 - If a composite signal contains frequencies between 1000 and 5000, its bandwidth is $5000 - 1000 = 4000$
- ▶ The Bandwidth of a composite signal is the difference between the highest and the lowest frequencies contained in that signal.



Bit Rate and bit length

- ▶ The Bit Rate is the number of bits sent in 1 sec, expressed in bps(bit per sec).
 - Bandwidth can also refer to the number of bits per second that a channel , a link, or even a network can transmit.
 - Example, one can say the bandwidth of a fast Ethernet network is a maximum of 100Mbps.This means that this network can send 100Mbps.
- ▶ The Bit length is the distance one bit occupies on the transmission medium.
 - Bit length= Propagation speed * bit duration